


# Kids Tipi Tent

ASSEMBLY INSTRUCTIONS

**MCM0120**



[www.robin-cool.com](http://www.robin-cool.com)

**Servicio Post-Venta**

Tel: +34 918 09 62 29


Email: [spv@kovyx.com](mailto:spv@kovyx.com)



# Kids Tipi Tent

## Assembly instructions

Please retain this information  
for future reference



### **⚠ WARNING:**

#### **CHOKING HAZARD** - Small parts.

Not for children under 3 years.  
Adult assembly by hand screwdriver required.

Adult assembly required, small parts and sharp point  
may be present prior to assembly

**ACHTUNG:** Erstickungsgefahr durch kleiner Teile.  
Nicht geeignet für Kinder unter 3 Jahren.  
Erwachsener Montage von Hand Schraubendreher  
erforderlich.

**ATTENTION:** Danger d'étouffement cause des petites  
pièces. Ne convient pas a des enfants de moins de 3  
ans.  
Assemblage adulte à l'aide d'un tournevis manuel  
requis.




**ADVERTENCIA:** PELIGRO DE ASFIXIA! Contiene  
piezas pequeñas que pueden ser tragadas. No apto  
para menores de 3 años.  
Se requiere montaje adulto a mano con destornillador.

**OSTRZEŻENIE:** RYZYKO ZADŁAWIENIA - małe  
części.  
Nie dla dzieci poniżej 3 lat.  
Montaż dorosłych za pomocą ręcznego śrubokręta.

**ATTENZIONE:** Parti di dimensioni ridotte. Pericolo di  
soffocamento. Non adatto a bambini al di sotto dei 3  
anni. Montaggio realizzato da un adulto.

**WAARSCHUWING:** Bevat kleine onderdelen die  
verstikkingsgevaar kunnen opleveren. Niet geschikt  
voor kinderen jonger dan 3 jaar. Moet door  
volwassenen in elkaar worden gezet.


**AVISO:** PERIGO DE SUFOCAMENTO - Peças  
pequenas. Não apropriado para crianças com menos  
de 3 anos de idade.  
Montagem realizada por um adulto.



Warning of sharp objects




1




Connect Left pole and Right poles by inserting two imperfrated ends into a plastic connector.

2




Slide the connected poles through fabric seams.

3




Lace the poles by successivwly threading the cotton string through the upper holes of all 4 combined poles.

4




Spread out the poles to the full extent, and then the tent is stably installed.

5



Tighten them up, Then you stand in the tent and insert the stabilizer (removing the upper part) into the middle of the pole.

6



Insert and tighten the upper end of the fixator